

WOODWRIGHT 2014 Designer Finishes

DF #011

State House Cherry

Wood species shown: CHERRY

→ Choose PreCat or Catalyzed & follow through with that type of product for the entire application. Please do not mix PreCat & Catalyzed finish.

Ingredients for **PreCat** Application:

- OCS106 Acres Stain
- Clear 8820-35 PreCat Sealer
- 530-060 Dark Burnish
- Clear 8828-45 PreCat Varnish

OR

Ingredients for **Catalyzed** Application:

- OCS106 Acres Stain
- Clear 9935 Catalyzed Sealer
- 530-060 Dark Burnish
- Clear 9930-35 Catalyzed Varnish

**Always catalyzed according to label instructions*

Instructions:

1. Prepare bare wood with 180 grit—flat surfaces and end grain should feel smooth to the touch
2. Apply 1 coat OCS106 Acres stain with rag or spray—wipe dry
3. Apply 1 coat clear varnish sealer at 5 wet mils—allow to dry completely
The following steps must be completed within 12 hours for proper adhesion. If you cannot sand and topcoat in the same day please wait to complete the next steps.
4. Sand thoroughly with 320 grit for adhesion of top coat
5. Apply burnish by lightly misting around edges and in profiles—allow to dry completely
6. Apply 1 coat of clear topcoat at 5 wet mils—allow to dry for 12 hours before wrapping



Disclaimer: The color shown is for illustrative purposes only. Due to difference in wood grain, sanding procedures and lighting, this color may only be used as an approximation of the color. **Obtaining a physical color sample is highly recommended.**

Please call 1.800.322.8172 for technical support if you have any questions.
Woodwright Quality Wood Finishes | 1225-C US Route 62 | Wilmot, Ohio 44689