

**WOODWRIGHT** 2014  
**Designer Finishes**

DF #022  
Asbury Burnish

Wood species shown: BROWN MAPLE

→ Choose PreCat or Catalyzed & follow through with that type of product for the entire application. Please do not mix PreCat & Catalyzed finish.

**Ingredients for PreCat Application:**

- OCS117 Asbury Stain
- Clear 8820-35 PreCat Sealer
- 530-060 Dark Burnish
- Clear 8828-35 PreCat Varnish

OR

**Ingredients for Catalyzed Application:**

- OCS117 Asbury Stain
- Clear 9935 Catalyzed Sealer
- 530-060 Dark Burnish
- Clear 9930-35 Catalyzed Varnish

*\*Always catalyzed according to label instructions*

**Instructions:**

1. Prepare bare wood with 180 grit—flat surfaces and end grain should feel smooth to the touch
2. Apply 1 coat OCS117 Asbury stain with rag or spray—wipe dry
3. Apply 1 coat clear varnish sealer at 5 wet mils—allow to dry completely  
*The following steps must be completed within 12 hours for proper adhesion. If you cannot sand and topcoat in the same day please wait to complete the next steps.*
4. Sand thoroughly with 320 grit for adhesion of top coat
5. Apply burnish by lightly misting around edges and in profiles—allow to dry completely
6. Apply 1 coat of clear topcoat at 5 wet mils—allow to dry for 12 hours before wrapping



**Disclaimer:** The color shown is for illustrative purposes only. Due to difference in wood grain, sanding procedures and lighting, this color may only be used as an approximation of the color. **Obtaining a physical color sample is highly recommended.**

Please call 1.800.322.8172 for technical support if you have any questions.  
Woodwright Quality Wood Finishes | 1225-C US Route 62 | Wilmot, Ohio 44689